



ROBOTIKA

Before using the Robot Vacuum Cleaner - you must turn it ON from the main switch. See below:



Lift the Top plate up
to access Power Switch



Slide the switch to ON
to power on the unit.

Slide it to OFF to power
off the unit.